

# CENTURION DISPLAY SCREEN MAP


OPERATIONAL  
SCREENS



NAVIGATION  
Use left and right arrow keys to move between top level screens.

CUSTOM SCREENS  
Up to 5 custom screens can be configured using MConfig Pro. Screens can be arranged in any order. However, all custom screens will appear after the ACTIVE ALARMS screen.

SETUP  
SCREENS




PASSWORD ENTRY  
0 (zero) = Read ONLY access to the Setup Screens.  
35 = Download ONLY  
  
Passwords for "Standard" and "Super User" are configured using MConfig Pro. Refer to CE-0517N pg. 23 for additional information on password functionality.

NAVIGATION  
Use left and right arrow keys to move between top level screens.



NAVIGATION  
Use left and right arrow keys to move between top level screens.

SETUP  
SCREENS  
continued...



NAVIGATION  
Use left and right arrow keys to move between top level screens.

SETUP  
SCREENS  
continued...



NAVIGATION  
Look for cues on screens to indicate what navigation is possible.

HOME  
Up to 5 custom screens can be configured using MConfig Pro.

One custom screen is configured as the default or "HOME" screen. While viewing the OPERATIONAL SCREENS, pressing the HOME key will jump from the currently displayed screen to the configured default screen.

This function is not available in SETUP SCREENS. However, pressing this key on any multi-line display when the first line is not being displayed will jump to the top or "HOME" line on that screen.