

# IntelliSpark® Integral Coils – Installation Instructions

**WARNING! Deviation from these instructions may lead to improper engine operation which could cause personal injury to operators or other nearby personnel.**

The IntelliSpark coils covered by these instructions are part numbers:

ITX-150-6	ITX-150-12	ITX-170-6
ITX-170-10	ITX-170-12	ITX-250-12

Integral coils mount directly to specially threaded spark plugs or adaptors. Proper installation must be used to obtain the designed life expectancy and performance of these coils. Excessive torque applied to the coil during installation could damage the internal seals of the spark plug, which can lead to contamination and/or heat damage to the coil from combustion leakage.

## Integral Coil Installation

Once the spark plugs have been installed as per the OEM's recommendations, the coils can be installed. NEVER torque the spark plugs using the integral coil.

Screw the coil onto the already properly installed spark plug until it is fully seated. Tighten the coil firmly by hand and then using a torque wrench, tighten the coil to 5 - 10 ft.-lbs. of torque. Never exceed 10 ft.-lbs. DO NOT use any thread lubricant between the coil and the spark plug.

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. FW MURPHY product names and the FW MURPHY logo are proprietary trademarks. This document, including textual matter and illustrations, is copyright protected with all rights reserved. (c) 2019 FW MURPHY. A copy of our typical warranty may be viewed or printed by going to [www.fwmurphy.com/warranty](http://www.fwmurphy.com/warranty).

### FW MURPHY PRODUCTION CONTROLS

SALES, SERVICES & ACCOUNTING  
4646 S. HARVARD AVE.  
TULSA, OK 74135

CONTROL SYSTEMS & SERVICES  
105 RANDON DYER ROAD  
ROSENBERG, TX 77471

MANUFACTURING  
5757 FARINON DRIVE  
SAN ANTONIO, TX 78249

### DOMESTIC SALES & SUPPORT

FW MURPHY PRODUCTS  
PHONE: 918 957 1000  
EMAIL: [INFO@FWMURPHY.COM](mailto:INFO@FWMURPHY.COM)  
[WWW.FWMURPHY.COM](http://WWW.FWMURPHY.COM)

FW MURPHY CONTROL SYSTEMS & SERVICES  
PHONE: 281 633 4500  
EMAIL: [CSS-SOLUTIONS@FWMURPHY.COM](mailto:CSS-SOLUTIONS@FWMURPHY.COM)

### INTERNATIONAL SALES & SUPPORT

CHINA  
PHONE: +86 571 8788 6060  
EMAIL: [INTERNATIONAL@FWMURPHY.COM](mailto:INTERNATIONAL@FWMURPHY.COM)

LATIN AMERICA & CARIBBEAN  
PHONE: +1 918 770 8775  
EMAIL: [INTERNATIONAL@FWMURPHY.COM](mailto:INTERNATIONAL@FWMURPHY.COM)

SOUTH KOREA  
PHONE: +82 70 7951 4100  
EMAIL: [INTERNATIONAL@FWMURPHY.COM](mailto:INTERNATIONAL@FWMURPHY.COM)



FM 668576 (San Antonio, TX - USA)  
FM 668933 (Rosenberg, TX - USA)



FM 523851 (China) TS 589322 (China)